



# MICROWAVE

## INSTRUCTIONS



- ✓ Place food on the ceramic shelf and close the door securely.
- ✓ Turn the Light Up Dial to the desired cooking time. Note that the light indicates the cooking time. Cooking will start Immediately.
- ✓ After cooking or reheating, leave foods in the microwave for 1-2 minutes for food to finish cooking and cool down
- ✓ Use hot pads or oven mitts to remove food in order to prevent burns.

## INSTRUCCIONES

- ✓ Coloque los alimentos en el estante de cerámica y cierre la puerta con firmeza.
- ✓ Gire el Light Up Dial para el tiempo de cocción deseado. Tenga en cuenta que la luz indica el tiempo de cocción. Cocinar comenzará inmediatamente.
- ✓ Después de calentar o cocer, deje los alimentos en el microondas durante 1-2 minutos para que los alimentos se termine de cocinar y enfriar
- ✓ Use toallas calientes o guantes de cocina para retirar los alimentos con el fin de evitar quemaduras

## WARNING

- X Do not turn the microwave on when it is empty.
- X Do not use aluminum foil, metal items, or dishes with metallic trim.
- X Do not use plastic food containers, unless identified as "microwave safe."
- X Do not use paper towels, plates or other utensils made from recycled paper.

## ADVERTENCIA

- X No encienda el horno de microondas en cuando está vacío.
- X No utilice papel de aluminio, artículos de metal, o platos con adornos metálicos
- X No utilice recipientes de plástico para alimentos, a menos identificado como "apto para microondas".
- X No use toallas de papel, platos u otros utensilios hechos de papel reciclado.

## CLEANING

- ✓ For easy cleaning, wipe any splatters or spills with a soft damp cloth or sponge at the end of each day. For heavier spills, use mild soap and rinse thoroughly with hot water.

## LIMPIEZA

- ✓ Para facilitar la limpieza, limpie las salpicaduras o derrames con un paño húmedo o una esponja suave al final de cada día. Para derrames más grandes, utilice jabón suave y enjuagar bien con agua caliente

